

# TB-68

## FOG NOZZLE CABLE KIT FIELD INSTALL

---

Date of issue: 12/10/03  
TB Revision level: 0  
Effects # : 104825 SERIES KITS

---

Note: This kit is for replacement of fog nozzle cables for elevated monitors.

### Parts list (as supplied)

- Cable pre-assembled with swivel snap links. ( length per sales order )
- Four 3/32 nico-press compression sleeves.
- Handles, one fog & one stream.

### Installation:

1. The pre-assembled cable has the snap swivels already installed. Cut cable in half and hook the snap swivels on the cable ends exiting the fog nozzle. One snap swivel on each side.
2. Be sure to note which cable (when pulled) makes the nozzle poppet travel out. This will be the cable which gets the Fog handle.
3. Route cables down through the brackets and grommets.
4. Trim cable to length making sure you have full travel for proper fog nozzle operation and enough for swaging cable on the handles.
5. Strip off approx. six inches of vinyl from cable ends and install handles.
6. Use two compression sleeves per end and make sure to use the proper Nico-press tool for sleeve installation.

### TYPICAL NICO-PRESS INSTALLATION

